

HOW THIS BOOK IS ORGANIZED

This manual is divided into seven major sections.

Section #1000	General Rules
Section #2000	Loading of Steel Products, including Pipe
Section #3000	Loading of Road, Grading and Farm Equipment Machinery
Section #4000	Not available/archived
Section #5000	Loading of Forest Products and Building Materials
Section #6000	Loading of Department of Defence Materials
Section #7000	Rules governing the Loading of Commodities of Open Top
	Trailer (TOFC) or container (COFC) Service
Section Test	CLR Loads under test

THE FIGURES

