



## DUNNAGE BAGS AND VOID FILLER

*Corresponding AAR Open Top Loading Rule 12*

Inflatable Dunnage Bags may be used in open top loading only when permitted in a specific figure. Bags may be used only for one loading and are not reusable. Effective October 1, 2001, inflatable dunnage bags used in open top loading must be AAR approved. Table of approved dunnage bags may be found on the AAR Web site at <http://www.aar.com/otlr.htm>

Honeycomb or similar Cell Void Filler Material must be AAR approved for use in open top loading. Honeycomb or similar cell void filler material is not acceptable for use in General Rule loads and may only be used in open top loading when permitted in a specific figure and all other requirements are followed. More than one filler piece may be placed together to fill a total void space of not more than 8 in. When permitted in a figure, separate void spaces of no more than 8 in. each may be filled with approved void filler.